

OVERALL CHECK LIST:

☐ Adhere to zero waste pattern, made without fabric waste
☐ All raw seams are serged or finished with zig zag stitches using matching thread color
☐ Ribbings are sewn on and top stitched
☐ Consider adding top stitches along arm hole and sleeve seams for reinforcement
☐ Measurement difference between spec and produced unit should be no more than +/- 0.5in, preferably +/- 0.25in or less.
☐ All stitches and sew-on accessories are clean, straight, tight, and free from loose threads
☐ Tension areas (under arm, corners around the neck) are reinforced


THIS DOCUMENT CONTAINS:

☐ Zero waste cuts
Specs
☐ Sewing instructions

HOODIE S/M Zero Waste Pattern

Materials: White organic cotton (1.22 yards) + white ribbing Matching White Thread


Organic Cotton Fabric 70.5in



HOODIE S/M Zero Waste Pattern


Materials: White organic cotton (1.22 yards) + white ribbing Matching White Thread


Ribbing 45 in



- * A 45 in x 15 in piece of ribbing creates three hems for the body and one set of cuffs. (See figure above)
- * For extra cuffs, align cuffs along the 45 in width, creating 5 cuffs with 4-5 in left that can be combined with another 4-5 in piece to create another cuff. (See figure below)

Ribbing 45in






HOODIE L/XL Zero Waste Pattern

Materials: White organic cotton (1.31 yards) + white ribbing Matching White Thread







HOODIE L/XL Zero Waste Pattern

Materials: White organic cotton (1.31 yards) + white ribbing Matching White Thread





^{*} Use the full 45 in of ribbing for either one hem or 5 cuffs/2.5 sets of cuffs.




HOODIE S/M + L/XL Sewing Instructions




- 1. Put the front and the back body pieces together, sew from the inside with a straight stitch along the two shoulders. This would be the ~26 in side, and each shoulder would be ~6.5 in of sewing.
- 2. Sew the left sleeve together by attaching the front and the back pieces from the inside along the diagonal. Repeat for the right sleeve.


- 3. Open the body and sleeve pieces and attach the left and right sleeves. Pin the body piece and the sleeve pieces together from the inside and sew the arm holes together with straight stitch.
- 4. Attach the pockets to the front by sewing in each side of the pocket by 0.25 in, then straight stitching the top and the bottom to the front body piece. Finally, top stitch each of the two bottom corners of the front pocket by 1.5 in up. This would better prevent items in the pocket from falling out.
- 5. Sew together the hood (see next page)




7. From the inside, bring the armpit corners together. Sew together along both sides from the arms to the sides of the body.




- 8. Take the ribbing for the bottom body hem, straight stitch together to make the ribbing into a tube. Do the same with the two cuffs.
- 9. Fold the ribbing tubes into halves by opening up the edges sewn together, fold in half, then flip the rest of the fabric over.





10. Attach the ribbings by sliding each tube over the hoodie bottom or over the sleeve, line up the seam edges, pin all the way around with even spacing, zigzag stitch around from the inside, then top stitch over the ribbing again for extra security.



HOODIE S/M + L/XL Sewing the Hood







Match the hoodie pattern pieces and sew together

- From the reverse side, sew together along the outside edges for both sides.
- Open the two pieces from 1 and sew together with one piece being the inside of the hood and the other piece being the outside of the hood. Leave the bottom open. Flip inside out so the outer layer is facing outward.

Eliminate any pointy corner on the back

Push in the pointy back corner, sew in from the inside of the hood. (Refer to your KATLA X SXD hoodie)